

DIMENSION	1/4"-3/8"-1/2"	3/4"	1"	1-1/4"	1-1/2"	2"	2-1/2"	3"
A (SR)	7-5/8"	8"	9"	9-1/2"	10-1/2"	11-5/8"	13"	14-3/4"
A (DA)	7.5/01	0.11	0.4/48	0.4/01	400	40.0/48	40"	4.411
A (DA)	7-5/8"	8"	8-1/4"	9-1/2"	10"	10-3/4"	13"	14"
B (SR)	7-3/4"	7-3/4"	8-1/4"	8-1/4"	10"	10"	10"	14-1/2"
D (0.1)	7 07 1	7 0/ 1	0 1/1	0 17 1	10	10		111/2
B (DA)	5-3/4"	5-3/4"	5-3/4"	6"	6"	6"	7-1/4"	7-1/4"
C (SR)	4-5/8"	4-3/4"	5-1/4"	5-1/2"	6-1/4"	6-5/8"	7-1/2"	8-3/8"
C (DA)	4-5/8"	4-3/4"	4-7/8"	5-1/2"	5-3/4"	6-1/8"	7-1/2"	8"
C (DA)	4-5/6	4-3/4	4-770	5-1/2	3-3/4	0-1/6	7-1/2	0
D	5/8"	7/8"	1"	1-1/4"	1-1/2"	1-7/8"	2-1/4"	2-3/4"
								-
E	3"	3"	3"	3"	3"	3"	3"	3"
F (SR)	1-5/16"	1-5/16"	1-3/4"	1-3/4"	2-1/8"	2-1/8"	2-1/8"	2-1/2"
F (DA)	1-5/16"	1-5/16"	1-5/16"	1-3/4"	1-3/4"	1-3/4"	2-1/8"	2-1/8"
i (DA)	1-5/10	1-0/10	1-0/10	1-0/4	1-0/4	1-0/4	2-1/0	2-1/0
G (SR)	1-7/8"	1-7/8"	2"	2"	2-1/2"	2-1/2"	2-1/2"	3"
G (DA)	1-7/8"	1-7/8"	1-7/8"	2"	2"	2"	2-1/2"	2-1/2"
II (CD)	3-1/4"	3-1/4"	3-3/8"	3-3/8"	3-7/8"	3-7/8"	3-7/8"	4-3/8"
H (SR)	3-1/4	3-1/4	3-3/8	3-3/6	3-776	3-776	3-1/6	4-3/6
H (DA)	3-1/4"	3-1/4"	3-1/4"	3-3/8"	3-3/8"	3-3/8"	3-7/8"	3-7/8"
(*					
J (SR)	2-5/8"	2-5/8"	3-1/2"	3-1/2"	4-1/4"	4-1/4"	4-1/4"	5"
	0.7(0)	0 = (0)	0 = (0)	0.4/05	0.440	0.4405	4 4/45	4 4/45
J (DA)	2-5/8"	2-5/8"	2-5/8"	3-1/2"	3-1/2"	3-1/2"	4-1/4"	4-1/4"
К	2-5/8"	3"	3-1/2"	4"	4-1/2"	5"	6-5/8"	7-1/4"
IX.	2-3/0	J	J-1/2	7	7-1/2	J	0-3/0	1-1/-
NOTE: "H" IS CENTERLINE TO OUTSIDE SURFACE OF SOLENOID-								

Series **S1-SS** with C-Series Pneumatic Actuator



